USER MANUAL

















THANK YOU for buying FLOWX series electric actuators of our company.

Before you install and connect parts and install the equipment on site and conduct control operation, please carefully read this manual.

Follow various instructions in the manual and you will get convenience and excellent performance at work.

Cautions

Make sure you observe them

- 1. When it is energized, it is forbidden to operate it manually.
- Inside the actuator, there is a over temperature protection device, so when electromotor temperature rises beyond 125°C, the overheat protector will turn off the power automatically.
- 3. When using it, you must mount an electricity leakage protection device.
- 4. Please make sure the input voltage and wiring connection points are correct.
- 5. You must not link the power lines of 2 or more electric drive devices in parallel connection. You must not control several electric drive devices from one single connection point. Or else, it may get out of control and the electromotor may superheat.
- The in-leads of wiring must have the sealing for waterproof cable connector according to operation manual. Or else, the
 electric drive device may be damaged due to intrusion of water or filthy mud.
- 7. The intelligent regulation type must be wired and commissioned according to operation manual, to avoid damage.
- 8. Installation and commissioning staff must have related operation qualification.
- 9. Electric drive devices must not be used under overload.
- 10. The manufacturer does not bear responsibility for improper change or repair of electric drive device.

Product Overview


FLOWX series electric actuators are new generation products we develop after importing foreign latest technology. 90 % of its components are imported with original packaging. So they have adequate assurance of stability of performance .FLOWX series electric actuators have high in telligence, high guarding ability, compactness, high degree of integration, long performance life, stable performance and other merits.


It allows operation on site. it also allows remote control. It suits ball valve, butterfly valve, throttle valve separating wall and other equipment that rotate by 90 degrees. It can satisfy various requirements of in dustier automation piping control. It has widespread use in many industries. Including: metallurgy, petroleum, chemical engineering, generating station, printing and dyeing, water treatment, shipbuilding, paper-making, food processing, pharmacy and building automation system etc.

Product Features

- 1. Strong features: intelligent regulation type, proportion type, switch type various signal output type, everything that you expect to find;
- 2. Small and light: it's volume and weight are merely equal to about 35% of traditional products;
- 3. Elegant appearance: aluminum alloy cast shell refined and fluent reducing electromagnet tic interference;
- 4. Reliable performance: key components like shaft bearings and electrical elements are imported famous-brand produces;
- 5. High protection standard: IP 68 high standard protection level [detected by Shanghai instrumentation and autonomous system inspection and test institute);
- 6. Precise and wear resistant: The worm wheel output shaft adopts integrated forging from special copper base alloy, and has high strength and good wearability;
- 7. Extremely small return difference: its integrated structure avoids the gap of key-joints, and has high driving accuracy;
- 8. Safety guarantee: it has passed 1500 V voltage endurance detection, it has class F insulation electromotor, and it has CE accreditation, so it has higher safety guarantee;
- 9. Simple to mate: it adopts single phase power supply and simple connection loop, and we can also make it 380 V or DC
- 10. Convenient to use: no need to oil and no need to make spot-check, and it is waterproof and rust-proof, and can install at any angle;
- 11. Multi-speed: its whole range time is 9 Seconds, 13 Seconds, 15 Seconds, 30 Seconds, 50 Seconds, 100Seconds, and 150 Seconds (already set when leaving factory);
- 12. Intelligent digital control: the intelligent control module is integrated in the electric actuator, so it need not connect an external localizer; digital setting, digital calibration, high precision, self-diagnosis, and multiple feature in one device.

Coding of the model





Spare and reserve parts

No.	Qty	Part name
1	1	Indication window hood
2	4	internal hexangular fillister head screw
3	1	Viewing glass
4	1	O-ring
5	1	Electric fitting: top cap
6	4	Anti-break off hex type socket screw
7	1	O-ring
8	1	Cross bolt
9	1	Dial
10	4	Cross bolt(component)
11	4	Travel switch
12	2	insulation plate guard
13	2	insulation pad
14	4	hex type socket holding screw
15	2	Stroke dog
16	4	Cross bolt(component)
17	1	Electric fitting: inner cap
18	1	Cross bolt(component)
19	1	Electric capacitor
20	1	Electric fitting: case body
21	2	Limit bolt
22	2	Hexagonal nut
23	1	Waterproof cable joint
24	1	Connecting terminal
25	2	Cross bolt
26	1	Cross bolt
27	1	O-ring
28	4	Anti-break off hex type socket screw
29	1	Electric fitting: lead-in cap
30	1	Bearing
31	1	Worm wheel
32	1	Bearing
33	1	Oil seal
34	1	hex type socket holding screw
35	1	Connecting bushing (IS05211)
36	1	Fixing base (ISO5211)


No.	Qty	Part name
37	4	Internal hexangular fillister head screw
38	1	Bearing
39	1	Worm screw
40	1	Flat key
41	1	Bearing
42	1	Locknut
43	1	Gear on worm
44	1	Axis shield ring
45	1	O-ring
46	1	Oil seal
47	6	Anti-break off hex type socket screw
48	1	Cross bolt(component)
49	1	Dustproof end plug
50	1	Electric fitting: front cap
51	1	Electric fitting: speed-down case 1
52	3	Bearing
53	3	Electric fitting: reduction gear component
54	3	Bearing
55	1	Electric fitting: speed-down case
56	5	Cross bolt(component)
57	1	Cross bolt(component)
58	1	Dial needle
59	1	Pointer rod
60	1	Rubber end plug
61	1	Wavy spring washer
62	1	Bearing
63	1	Insulating division board
64	1	Electromotor stator
65	1	Electromotor rotor
66	1	Bearing
67	1	Insulating division board
68	1	Electromotor cap
69	1	Oil seal
70	1	Oil seal stop plate
71	2	Cross bolt(component)

Note: This structure diagram is for FLOWX-10B-30S-AC220V-F05-07-NN (power-less contact point type)

FLOWX-05 series dimensions and performance parameters

Standard type

Direct installation type(ISO5211 standard)




Model		FLOWX-05							
Power supply	DC12V	DC24V	DC220V	AC24V	AC110V	AC380V	AC220V		
Power		20W			10)W			
Rated current	3.8A	2A	0.21A	2.2A	0.48A	0.15A	0.24A		
Output moment		30Nm/50Nm			15Nm/30	Nm/50Nm			
Running time		6S/10S			10S/20	OS/30S			
Control loop			Туре	e A,B,C,D,E,F,	G,H				
Rotation angle			0-	-360° adjustab	le				
Whole machine weigh				2.4kg					
Insulation resistance		100MΩ/300VD	С		100ΜΩ/	500VDC			
Voltage endurance level	5	00VAC/1 minu	ite		500VAC	/1 minute			
Protection level				IP67					
Ambient temperature	-25°C~60°C (other temperature range is open for customizing)								
Installation angle	360°,any angle								
Shell material			Aluminum alloy	precision pre	ss-forged piece				
Optional features heater				Dehumidifier					

FLOWX-10 series dimensions and performance parameters

Standard type **Direct installation type(ISO5211 standard)** 154 211.5 211.5 77 57 97.5 114 97.5 114 145.5 168.5 PLÓWX° PLÓWX° Electric Actuator Electric Actuato 32 □15×15 φ90 98 Direct-installation type parameters(ISO5211 standard) φ70 82 4 - M611*11 14*14 17*17 Square socket ф50 4-M8 Flange F05 F07 4 - M6 φ70 Valve rod Height ≤28mm 45°

Model				FLOWX-10				
Power supply	DC12V	DC24V	DC220V	AC24V	AC110V	AC380V	AC220V	
Power		40W			23	BW		
Rated current	4.8A	2.4A	0.32A	3A	0.64A	0.19A	0.32A	
Output moment		100Nm			50Nm/60N	Nm/100Nm		
Running time		10S			13S/15S	/20S/30S		
Control loop			Тур	e A,B,C,D,E,F,	G,H			
Rotation angle			()-90° adjustable	e			
Whole machine weigh				4.2kg				
Insulation resistance	1	00MΩ/300VDC	;		100ΜΩ/	500VDC		
Voltage endurance level	50	00VAC/1 minut	е		1500VAC	C/1 minute		
Protection level				IP67				
Ambient temperature		-25℃~6	0°C (other temp	erature range i	s open for custo	omizing)		
Installation angle	360°,any angle							
Shell material		Aluminum alloy precision press-forged piece						
Optional features heater			Over-moment p	orotection, heat	er dehumidifier			

FLOWX-20/40/50/60 series dimensions and performance parameters





Model			FLOW	/X-20/40			FLOWX-50/60					
Power supply	DC24V	DC220V	AC24V	AC110V	AC380V	AC220V	DC24V	DC220V	AC24V	AC110V	AC380V	AC220V
Power			40V	V/60W					9	WO		
Rated current	8A	0.35A	5A	0.9A	0.25A	0.48A	7A	0.9A	8A	2A	0.45A	0.92A
Output moment	200	0Nm		200Nm	/400Nm				500Nn	n/600Nm		
Running time	1	0S		15S/3	0S/60S				158/3	30S/60S		
Control loop						Type A,B,C	,D,E,F,G,I	1				
Rotation angle						0-90° ad	ljustable					
Whole machine weigh			7.	2KG					8	KG		
Insulation resistance	100M Ω	/300VDC	100M Ω /500VDC			100M Ω /300VDC 100M Ω /500VDC						
Voltage endurance level	500VAC	c/1 minute		1500VA	C/1 minute		500VAC/1 minute 1500VAC/1 minute					
Protection level						IP	67					
Ambient temperature				-25℃~6	60°C (other t	emperature	range is o	pen for cus	tomizing)			
Installation angle		360°,any angle										
Shell material		Shell material Aluminum alloy precision press-forged piece										
Optional features heater					Over-mom	ent protection	on, heater	dehumidifie	r			


FLOWX-100/200 series dimensions and performance parameters


Standard type

Direct installation type(ISO5211 standard)









Direct-installation type parameters(ISO5211 standard)							
	1	100 200					
Causes applied	22	2*22	27*27				
Square socket	27	7 *27	36*36				
Flange	F10	F12	F14	F16			
Valve rod	Height	≤40mm	Height	≤60mm			

Model		FLOWX-100				FLOV	NX-200	
Power supply	AC24V	AC110V	AC380V	AC220V	AC24V	AC110V	AC380V	AC220V
Power		10	DOW WOO			1(W0C	
Rated current	9A	2.2A	0.48A	1.2A	9A	2.2A	0.48A	1.2A
Output moment		300Nm/800	0Nm/1000Nm			200	00Nm	
Running time		15S/3	30S/50S			1	00S	
Control loop				Type A,B,C	C,D,E,F,G,H			
Rotation angle				0-90° a	djustable			
Whole machine weigh		11	.5Kg			12	.1Kg	
Insulation resistance				100M/5	500VDC			
Voltage endurance level				1500VAC	C/1 minute			
Protection level				IP	67			
Ambient temperature		-25°C~60°C (other temperature range is open for customizing)						
Installation angle	360°,any angle							
Shell material		Shell material Aluminum alloy precision press-forged piece						
Optional features heater			Over-mo	oment protecti	on, heater de	ehumidifier		

Intelligent adjustment type (E type) performance parameters

Model	FLOWX-05E	FLOWX-10E	FLOWX-20E	FLOWX-40E	FLOWX-50E	FLOWX-60E	FLOWX-100E	FLOWX-200E
Power supply		DC12V,DC24V,DC220V,AC24V,AC110V,AC220V,AC380V; 50/60Hz						
Electromotor power	10W	23W	40W	40W	90W	90W	100W	100W
Rated current	0.24A(AC220V)	0.32A(AC220V)	0.48A(AC220V)	0.48A(AC220V)	0.92A(AC220V)	0.92A(AC220V)	1.0A(AC220V)	1.2A(AC220V)
Output moment	50Nm	100Nm	200Nm	400Nm	500Nm	600Nm	1000Nm	2000Nm
Running time	30S	30S	30S	30S	30S	30S	50S	100S
Rotation angle	0-90°	0-90°	0-90°	0-90°	0-90°	0-90°	0-90°	0-90°
Whole machine weight	2.4Kg	4.2Kg	7.2Kg	7.2Kg	8Kg	8Kg	11.5Kg	12.1Kg
Input signal		4-20m <i>F</i>	A DC, 1-5VDC, 0)- 10VDC (others	s can be selecte	d before leaving	factory)	
Output signal			4-20mA DC (others can be s	elected before le	eaving factory)		
Basic deviation				*no greate	er than ±1%			
Return difference				*Less th	nan 0.3%			
Dead zone				0.4%-1.5%	6 adjustable			
Damping feature				0 ti	mes			
Device repetitive error				0	0%			
Insulation resistance	DC2	4V: 100MΩ/300	VDC			100MΩ/500VD0		
Voltage endurance level	DC24	4V: 500VAC/1 m	ninute		1	500VAC/1 minu	ite	
Protection level				IF	P67			
Ambient temperature		-25°C - +60°C(other temperature range is open for customizing)						
Installation angle		360°, any angle						
Shell material			Alumi	num alloy precis	sion press-forged	d piece		
Optional features		Over-	moment protect	ion, heater dehu	umidifier, power-	less contact poi	nt type	

Control Loop

Common switch type (A)

Valve open/close operation is realized by switch loop, and a set of powered position signal is output to signify the valve being full-open or full-shut.

Wiring method:

- Terminal 1 connects zero line of the power supply;
- When power supply phase line connects to terminal 2, it runs "ON", till the travel switch OLS acts;
- 3. When power supply phase line connects to terminal 3, it runs "OFF", till t he travel switch CLS acts;
- 4. When power supply phase line connects to terminal 2, it runs "ON", and when it runs in place, The "full-open signal" indicator connected to terminal 4 lights up;
- When power supply phase line connects to terminal 3, it runs "OFF", and when it runs in place, the "full-shut" indicator connected to terminal 5 lights up.

Power-less contact point type (B)

Valve open/close operation is realized by switch loop, and a set of powered position signal is output to signify the valve being full-open or full-shut.

Wiring method:

- 1. Terminal 1 connects zero line of the power supply;
- When power supply phase line connects to terminal 2, it runs "ON", and when it runs till travel switch OLS acts:
- When power supply phase line connects to terminal 3, it runs "OFF" till travel switch 3. CLS acts:
- 4. Terminal 4 is power-less contact point common terminal;
- When" ON " runs in place, the terminal 5 outputs "full-open signal";
- When" OFF" runs in place, the terminal 6 outputs "full-shut signal";

Openness degree signal type (C)


Valve open/close operation is realized by switch loop, and electric resistance signal is output corresponding to the openness position.

Wiring method:

- Terminal 1 connects zero line of the power supply;
- When power supply phase line connects to terminal 2, it runs "ON", and when it runs till travel switch OLS acts;
- When power supply phase line connects to terminal 3, it runs "OFF" till travel switch
- Terminal 4 is the low end of the potentiometer, so when running "ON", the impedance between terminal 4 and terminal 5 increases with the valve opening;
- 5. Terminal 5 is the movable arm of potentiometer;
- Terminal 8 is the high end of the potentiometer, so when running "OFF", the impedance between terminal 5 and terminal 6 increases with the valve closing;

Note: In the control loop, the part inside the dotted line is the internal loop of the electric-driven device, and the part outside is for reference by the user while wiring.

Caution!: Never connect the power cords of two or more electric-driven devices in parallel, never control multiple electric-driven devices with one single contact point, or else the system may malfunction or the electromotor may overheat.



6

White

Black

Yellow


Blue


SHUT-LAMP


OPEN-LAMP

SHUT

OPEN








With position transmitter (D)

Valve open/close operation is realized by switch loop, and electric current signal is output corresponding to the valve openness angle.

4-20mA DC valve-location signal is output (to exercise travel feedback to valve location).

Wiring method:

- On the power input side "N" is the zero line, and, "L" links to phase conductors;
- When" L" on the power input side links to "ON ", it runs to the direction of opening the valve;
- When" L" on the power input side links to "OFF", it runs to the direction of closing the valve:
- The" +" on the "output signal" side links to the positive pole of the output signal, and" " links to the negative pole of output signal.



Intelligent adjustment type (E)

The external computer or industrial instrument inputs a standard signal to control the open/shut degree of the valve and meanwhile feedbacks the corresponding standard signal.

Wiring method:

- On the power input side "N" links to the zero line, and, "L" links to phase conductors;
- The" +" on the "external control" side links to the positive pole of the input signal, and" " links to the negative pole of input signal.
- The" +" on the "feedback" side links to the positive pole of the output signal, and" " links to the negative pole of output signal.

By switching over the positive/negative polarity of the external DC power supply, the

valve "OPEN" or "SHUT" operation is realized, and meanwhile a set of power-less contact point signal is output to signify the value being full-open or full-shut.


DC switch type (F)


Wiring method:

- When terminal 11 inks to power supply positive pole, terminal 2 links to the power supply negative pole, and that is "ON" operation; SHUT
 - When terminal 11 inks to power supply negative pole, terminal 2 links to the power supply positive pole, and that is "OFF" operation;
- 3. Terminal 4 is power-less contact point common terminal;
- 4. When" ON " runs in place, the terminal 5 outputs "full-open signal";
- When" OFF" runs in place, the terminal 6 outputs "full-shut signal";

Note: In the control loop, the part inside the dotted line is the internal loop of the electric-driven device, and the part outside is for reference by the user while wiring.

Caution!: Never connect the power cords of two or more electric-driven devices in parallel, never control multiple electric-driven devices with one single contact point, or else the system may malfunction or the electromotor may overheat.






3-Phase switch type (G)

Valve open /close operation is realized by switch loop, and a set of powered position signal is output to signify the valve being full-open or full-shut.

Wiring method:

- Terminal 1, 2, 3 link to three-phase alternating current, and external phase inverting circuit is used to realize positive and negative rotation of electromotor;
 - Terminal 4 is the common point of external control loop;
 - Terminal 5 is " ON" operation control;
 - Terminal 6 is " OFF" operation control;
- 5. When" ON " runs in place, the terminal 57 outputs "full-open signal";
- 6. When" OFF" runs in place, the terminal 8 outputs "full-shut signal";



3-Phase power-less contact-point type (H)

Valve open /close operation is realized by switch loop, and a set of powerless position signal is output to signify the value being full-open or full-shut.

Wiring method:

- Terminal 1, 2, 3 link to three-phase alternating current, and external phase inverting circuit is used to realize positive and negative rotation of electromotor;
- 2. Terminal 4 is the common point of external control loop;
- 3. Terminal 5 is" ON" operation control;
- 4. Terminal 6 is " OFF" operation control;
- 5. Terminal 7 is power-less contact point common terminal;
- 6. When" ON " runs in place, the terminal 8 outputs "full-open signal";
- 7. When" OFF" runs in place, the terminal 9 outputs "full-shut signal";

Note: In the control loop, the part inside the dotted line is the internal loop of the electric-driven device, and the part outside is for reference by the user while wiring.

Caution!: Never connect the power cords of two or more electric-driven devices in parallel, never control multiple electric-driven devices with one single contact point, or else the system may malfunction or the electromotor may overheat.

Use requirements

Installation environment requirement

- The product can be installed indoors or outdoors;
- The product is not explosion protection product so please avoid flammable and explosive environment;
- 3. In an environment where there is rainwater, raw material splatter, and sunlight direct radiation on long term, you must install a protective hood to shield over the whole electric actuator.
- 4. Please reserve room for wiring, manual operation and installation and repair work;
- 5. Periphery environmental temperature should keep in 30 60°Crange;

Note: when using it in environment of big temperature difference or below zero point, you should use the model which has heater dehumidifier to prevent moisture condensation.

Working medium temperature requirement

- 1. When mating with valve, the working medium temperature is transmitted to actuator, and make its temperature rise;
- 2. When the working medium has high temperature, the bracket linking to valve works to reduce heat conducting;
- 3. When the working medium temperature is below 0°C, please select standard bracket;
- 4. When the working medium temperature is above 80°C, please select high temperature bracket;

On-site cable lines, wiring tubes installation requirement

- 1. When using wire tube, please install as per Fig.(1)
- a) wiring tube outer diameter ⊕8-12
- b) It should have adequate waterproof countermeasure
- The actuator shall be higher than wiring tube, so the water drops in wiring tube can't flow into actuator, thus ensuring its safety;
- 2. When using cable, its outer diameter is Φ 8-12. See Fig.(2). Cable that mismatch the waterproof cable connector inner diameter must not be adopted, or else the water can flow form waterproof cable connector into actuator and damage all internal components;
- 3. Signal wire in principle shall adopt shrouding wire, and its wiring should be separate from power line wiring.


Power supply requirement


- According to power supply type of the model you order, you provide relevant on-site power supply;
- 2. The voltage of on-site power supply shall comply with the following requirements:

AC380V \pm 10% 50/60Hz AC220V \pm 10% 50/60Hz AC110V \pm 10% 50/60Hz AC24V \pm 10% 50/60Hz DC24V \pm 5%

Selection of breaker switch fuse:

Model	Voltage	AC380V	AC220V	AC110V	AC24V	DC220V	DC24V	DC12V
FLO	NX-05	2A	2A	3A	5A	2A	5A	10A
FLO	NX-10	2A	3A	5A	7A	3A	7A	14A
FLOWX-2	20/40/50/60	3A/5A	5A/7A	7A/10A	10A/11A	5A/7A	15A	
FLOWX	(-100/200	5A	7A	10A	20A	20A		





Actuator and valve installation

Actuator and valve installation (Fig. 3)


- 1. Manually operate the valve, make sure there is no abnormal condition, turn the valve to full-shut position;
- 2. Lightly fix the bolt to the valve with a bracket;
- 3. Fit one end of the coupler over the valve stem;
- 4. Drive the electric actuator by manual handle to the full-shut position (Pointer just points to SHUT, 0 mark), insert the output shaft in the square hole of coupler;
- 5. Lightly fix the electric actuator to the bracket with a bolt;
- 6. Drive the electric actuator by manual handle through its full travel range. Make sure the operation is smooth, without deviation from center, and without skew or blockage, and examine whether the valve can realize full-shut and full-open within the openness indication range of the actuator.


Note: Don't use forcibly strong force, or else the actuator may run beyond limit and be damaged.

Special hints:

If you prepare your bracket or coupler by yourself, please notice:

- 1. Bracket and coupling shall be designed and processed by specialized technicians and conform to remark requirements in Fig. 4;
- 2. The axis hole processing on both ends of coupling shall guarantee necessary precision, and remove transmission gap as far as possible, in case the valve has return difference while working;
- You shall strictly guarantee position of axis holes on both ends of coupling. Or else it may go beyond actuator's designed scope of work .And the result is actuator travel range can't adjust and thus the valve cannot work normally.






Complete-machine debugging of electric valve

Switch type adjustment

- 1. Electric limiter adjustment
- a) Before adjusting the electric limiter, you shall loosen adjusting screw of mechanical limiter, and when the electric limiter is adjusted, retighten the mechanical limiter, to avoid mechanical blockage;
- b) Loosen the screw of stroke dog, and tap the stroke dog with screwdriver, so you can adjust the angle of stroke dog, thereby change the switch angle of electric limiter, and when travel switch acts, it gives the "kata" noise. In the end, firmly fasten the screw of stroke dog.
- ♦ When it is energized, it is forbidden to operate it manually.
- ♦ When you adjust the actuator whose angle of rotation adjustment range is 0~90 degrees. You should not adjust beyond range, or randomly enlarge the rotating angle.



Two switches overlap'
Upper is the ON limit switch
Lower is the OFF limit switch

Clamping nut


Adjusting screw

2. Mechanical limiter adjustment (Fig. 8)

 a) Drive the actuator by manual handle to the full-shut position (when travel switch acts, it gives " kata " sound);

Loosen locknut, clockwise turn the adjusting screw, to make it contact with mechanical stopper, and then counterclockwise turn the screw for half-lap, to let the mechanical limiter at the full-shut position lag behind the electric limiter by about 2~3° angular distance, and fasten the nut;

- In the same method, you can adjust the mechanical stopper at the full-open position.
- The electric limiter position and mechanical limiter position of the actuator must meet the requirement of (Fig. 9) .If mechanical limiter is ahead of or coincides with electric limiter, actuator electromotor may be blocked .It can heat up and even burn the electromotor.



- 3. Adjustment of potentiometer (Fig, 10), suitable for Type C, E (generally, no need to adjust)
- a) Resistance value of potentiometer is: $1K \Omega (5K \Omega)$;
- b) Drive the actuator by manual handle to its full-shut position;
- c) Loosen the screw of openness degree gear, and turn the openness degree gear. Adjust the potentiometer, measure the resistance between connecting terminals 4~ 5 with universal meter, make the resistance about I00.Fasten the openness degree gear locknut. (if it is the adjustment type seven-line plug-and-socket connection, please measure resistance corresponding to two jack holes RV and RS).
- You can also directly loosen potentiometer to adjust, but when fixing it, please notice the engagement between potentiometer gear and openness degree gear, and the gap shall not be too big or too tight, or else the actuator's complete machine precision will be directly affected.





Fig. 10


Debugging of the adjustment type (E)

A. How to adjust the adjustment type

Adjustment of actuator

1. Before you adjust the intelligent locator, please understand the adjusting method of switching angle, and adjust the actuator electric limiter and potentiometer mechanical limiter according to valve full-shut and full-open.






B. locator panel


Parameter	1	LED	By pushing buttons, you toggle from indication of valve actual openness value, valve setting openness value,
indication	ļ	view	locator shell inside temperature to setting parameters
	2	OPEN	Output controls" OPEN' current-breaker to close
Status	3	SHUT	Output controls" SHUT current-breaker to close
indication	4	MANU	Manual operation status
	5	AUTO	Automatic status
			Positive act mode, the input signal corresponds to output as follows:
	6	DRTA	4 mA Fullness position (generally calibrated as full-open);
			20 mA zero position (generally calibrated as full-shut)
Mode			Negative act mode, the input signal corresponds to output as follows:
indication	7	RVSA	4 mA zero position (generally calibrated as full-shut;
mulcation			20 mAfullness position(generally calibrated as full-open)
	8	OPEN	When input signal gets interrupted, it is "OPEN", to open the actuator till the maximum opening limit
	9	STOP	When input signal gets interrupted, it is 'HALT', to stop the actuator at current position
	10	SHUT	When input signal gets interrupted, it is 'SHUT" to open the actuator to the minimal opening limit
	11	A/M	Manual operation / auto operation switchover; the button to access modification of and toggle between
	• •		parameters
Button	n 12		Value increase button; in the automatic status it also toggle to indicate valve location setting openness value,
			and in manual operation status, it is "OPEN"
	13	•	Value decrease button; in the automatic status it also toggle to indicate temperature inside locator shell, and
	-		in manual operation status, it is "SHUT"

C. Wiring explanation

ZXQ2004 intelligent locator and electric actuator link up through a seven-line plug-and-socket connection.

1. On the locator, there is a six-line elastic clamp line contact bank (Fig. 11). N, L link to mean line and phase line of 220VAC Single-phase power, two IN terminals 4~20mA (or 1~5V) link to control current (voltage), two terminals 4~20mA link to current meter, to indicate actual valve opening and they may also be idle, not linked. Connecting wire can use single core or multi-core infrared insulated wire of conductor core 1~2mm (Fig.12), and remove the 7 mm insulation skin. If you use multi-core line, you would better twist tight and apply tin to it, thus the connection is easier, and when wiring you can insert single core wire or tinned multi-wire to the hole, and after sensing a resistance you continue to insert 4~5 mm, and that is enough; if the wire is too soft, you can put the wire in hole, and after sensing resistance, you use flat tip screwdriver to press the elastic clamp switch on rim of the corresponding hole, and then insert the line by 4~5 mm, and then loosen the elastic clamp switch, thus clamp the wire. After wire is clamped, it can't slip out normally. If you need to pull it out, use flat tip screwdriver to press the elastic clamp switch on the corresponding hole rim. Then you can pull wire out.






D. The setting and operating method for intelligent locator

According to the wiring diagram, link up the given signal source, locator, electric actuator, output signal measuring instrument and wires between power supply.

- 1. Power on, and now it indicates the actual openness degree of valve location, and locator is in the automatic detection and control status;
- Press A/M button to switch to manual operation status, and respectively press and buttons, and the detection actuator now shall correspond to "open" and "shut" action;
- In automatic status, press ▲ to check the valve location setting openness value, and now you can examine the change trend and stability
 of input signal;
- 4. In automatic status, press ▼ to check the temperature inside locator shell, and when temperature exceeds 70°C (you can correct it), the locator stops control over the open or shut of actuator.
- In automatic status, press A/M button for 4 seconds, to access parameter setting as shown in the next table. Parameters values can be modified by ▲ and ▼ button, as detailed in the operation flowchart.



Parameters list

Parameter	Indicated value	Description	Ex-works value
	00x.0	X = 1 allows electric brake, x=O disallow electric brake 1	1
UO	000.X	(1) $x = 0$ disallow change of positioning accuracy, yet allows change and reset of time	0
	000.X	(2) $x = 1,2,3$ does not change or reset time, but allows change of positioning accuracy	1
U1	00x.0	Set the positive and negative action.; $x=0$ is positive, $x=1$ is negative	2
01	000.x	Interrupt signal mode. X = 0 (neglect) x=l(open)x=2 (halt)x=3 (shut)	0
		Controls the output lower limit value 0 ≤U2<100, 0; manual operation	
U2	xxx.x	and the process of calibrating zero position and fullness position are	100
		not restricted by this parameter	
		Controls the output upper limit value 0 <u2<u3≤100, 0;="" manual<="" td=""><td></td></u2<u3≤100,>	
U3	xxx.x	operation and the process of calibrating zero position and fullness	0.4
		position are not restricted by this parameter	
U4	00x.x	Precision tunable, equal to x.x / 100	0.5
U5	XXX.X	Operation password, (U5 = 003.1, access the actuator openness	
03	****	degree calibration)	
		Confirm actuator zero position, operate $lacklacklacklack$ key, and when reaching	
U6	xxx.x	the setting zero position, press A/M button to confirm zero position,	
		then access	
		Confirm actuator zero position, operate $lacktriangle$ key, and when reaching	
U7	xxx.x	the setting fullness position, press A/M button to confirm fullness	
		position	

Note: other parameters are reserved by the company's use, and if you need them, please refer to the appendixes.

Actuator already finishes calibration before it leaves factory. User need only link the power supply, signal source and output signal measuring instrument (or idle it) .Then you can use it directly. No need to calibrate again. If you really need re-calibrate, you can follow the next steps to operate.

Calibrating the zero position and full-position of the actuator does not influence the input and output signals of locator. After actuator is readjusted, we must calibrate the actuator turning angle, and thereafter the locator can work normally. There are two methods of calibration:

Method 1 (manual calibration) (refer to operation flowchart 13):


- Access U5, modify U5= 003.1, then press A/M button again. Access U6 parameter (calibrate the zero position). Press ▲ or ▼, and actuator runs to "OPEN" or "SHUT" direction correspondingly, and meanwhile it shows the valve location actual openness value which gradually increases or decreases. When reaching expected zero position (normally the full-shut position), press A/M button to confirm zero position, and access U7 parameter;
- 2. Access U7 parameter (calibrate the full position), likewise, press ▲ or ▼ to the expected full position (normally the full-open position), and press A/M button to confirm full position, and the actuator automatically returns to 90 % position and return to U5;
- 3. Modify U5 = 000.5, return to the detection and control status.

Method 2 (Automatic calibration):

- 1. Access U5, modify U5= 003.1, press A/M button, and at the same time push down ▼ button, then release both, so you start up the automatic calibration. At this moment, the locators first calibrate the zero position, and then calibrate the full position. After calibration finishes, the locator is in the manual operation status. again access parameter us .Modify U 5 = 000.5(default value) and then press A/M button, and then the calibration result is saved;
- 2. During detection control process of locator, actuator may oscillate and heat up due to input signal quality and external Electro-Magnetic interference, so to avoid continued oscillation of actuator, you can modify U0 (000.x): set X= 0. Then when the actuator oscillates, the positioning accuracy keeps the setting precision. Yet, the actuator reset time will keep enlarging to 7 seconds, thereby reaching the requirement of exact positioning and intermittent work of actuator.

X = 1, 2, 3, then when actuator oscillates the reset time remains unchanged (about 2 seconds), but the actuator precision will keep minimizing, thereby reaching the requirement of working at most suitable precision.

Note: During the parameter modification process.



Error code list

Error code	Meaning
E-01	Control signal interrupted or lower than 0.3 mA
E-03	Signal feedback line between locator and actuator or the OPEN-SHUT line is connected in the reverse way, or the program operation is in error
E-05	Actuator has great oscillation, maybe due to instable input signal or feedback signal or too high precision
E-06	Actuator is blocked when moving to shutdown direction
E-07	Actuator is blocked when moving to opening direction
E-08	Locator shell internal temperature exceeds 70 ℃

Other calibrating operation --- input signal, output signal calibrating method (Fig. 14)

After it leaves factory, normally you need not operate this .If you really need please use it under engineer guidance.


1. Input signal calibration

- a) When locator is in normal detection control status, press A/M button for 4 seconds, to access setting parameter status; it shows" U0" parameter value. Press A/M button and select U5" parameter Press ▲,▼ to modify" U5" value, to make it 011.1: (value meaning is given in next table)
- b) Access" U8 " parameter value, to calibrate input current zero point: when calibrating, use an external meter to input the zero point signal (normally 4 mA), and press A/M button to confirm .Then access" U9 " parameter;
- c) Access" U9" parameter value to calibrate input current full range: when calibrating, use an external meter to input the full range signal (normally 20 mA), and press A/M button to confirm .Then access "U5" parameter: modify U5 = 000.5, press A/M button to confirm and exit, and thus the calibration finishes.
- The aforesaid operation process must ensure input signal is clean and stable.

2. Output signal calibration

- a) Access U5 parameter, modify U5= 001.1, then press A/M button to access U6 parameter; skip parameters U6, U7, U8, U9, and access "Ua";
- b) "Ua " calibrates output current zero point: when calibrating, operate ▲,▼ button, to calibrate output to 4 mA or other value, which corresponds to actuator zero position output signal value, and press A/M button to confirm; then access" Ub " parameter;
- c) "Ub " calibrates output current full range: when calibrating, operate ▲,▼ button, to calibrate output to 20 mA or other value, which corresponds to actuator full-position output signal value, and press A/M button to confirm; then access" Uc " parameter;
- d) "Uc" parameter modifies temperature inside shell; operate ▲,▼ button to modify it; Press A/M button to confirm, and then return to "U5" parameter, and modify" U5" numerical value U5= 000.5, press A/M button to confirm, and return to detection and control status.

Parameter	Indication value	Meaning	
		Access the calibration password: U5=011 .1 ,access input current calibration;	
U5	0XX.X	U5=001.1, access output current calibration;	
		U = 003.1, access actuator zero and fullness positions calibration	
U6	XXX.X	Actuator zero position parameter confirmation	
U7	XXX.X	Actuator fullness position parameter confirmation	
U8	XXX.X	Calibrate input current zero point parameter	
U9	XXX.X	Calibrate input current full range parameter	
Ua	XXX.X	Calibrate output current zero position parameter	
Ub	XXX.X	Calibrate output current full range parameter	
Uc	0.XX.X	Modify shell inside temperature	



Use and maintenance

Note: before the product leaves factory, it has already passed comprehensive debugging and examination.

When installing and connecting the product and valve, for reason of valve coupling etc., the valve may not be able to do full-open, full-shut, and so it need readjustment.

When adjusting, please follow following steps:

- . Install and connect the actuator and valve correctly;
- 2. Manually operate trial run;

Take off the dustproof end plug from front cover; insert the attached handle in the hexangular hole. Clockwise turn it, and valve openness degree shall decrease; when the valve is full-shut, observe whether the travel switch in the shutting direction acts (when the switch acts, it gives "kata" sound) and then turn the handle, examine whether the mechanical stopper touches the adjusting screw; counterclockwise turn the handle, and valve openness degree shall increase; in the same method, examine the travel switch and mechanical stopper in the opening direction, and after the manual operation trial run finishes, plug back the dustproof end plug.

3. Electric drive trial run:

Demount the lead-in cap .Wire up according to wiring diagram;

Electrify and conduct a trial run. Pay attention to observe whether the actuator and valve work normally.

A. Maintenance and service

- As the product has compact structure, it uses in particular long life high pressure-resistant top grade molybdenum lubricating grease, so it needn't spot-check or oiling.
- When electric valve does not work for long time or seldom works, please regularly drive the actuator to examine whether it malfunctions.

B. Malfunction and countermeasure

Manufiction and Countermeas	Jul 0	
Breakdown phenomena	Cause	Countermeasure
	Not linked to power supply	Connect power supply well
	Power supply voltage wrong or too low	Examine whether supply voltage is normal
	Broke wire, connector breaks away from terminal	Connect wire well, correctly connect the fastening termina
		Lower the surrounding environment temperature, and
	Overheat protector acts(is environmental temperature too high? is valve blocked?)	examine valve open/close action by manual method to see
Electromotor does not turn		whether it runs normally
		Reduce frequency of use
		Too heavy load
	Travel switch already acts;	Adjust the stroke dog
	Electromotor phase-advancer capacitor broken	Contact manufacturer to replace capacitor
	DC actuator diode broken	Contact manufacturer to replace diode
Switch pilot lamp does not light up	Pilot lamp broken	Replace pilot lamp
Switch phot lamp does not light up	Travel switch acts abnormally;	Replace travel switch
	Travel switch acts abnormally;	Replace travel switch
	Three-phase alternating-current supply has	Adjust three-phase alternating-current supply phase
When running to limit position, the	reversely connected phase sequence	sequence
electromotor does not stop turning	Travel switch has error when connecting into control loop	Adjust wiring
	Mechanic limiter acts ahead of the electric limiter	Readjust mechanic stopper according to the adjustment
		direction of mechanic limit stopper
	Electric fitting viewing mirror broken	Contact manufacturer for repair
	Electric fitting top-cap, lead-in cap, front cap etc.	
Actuator is intruded by water	Has a bolt not clamped.	
Actuator is introded by water	Lead-in cable is not normal, or in-lead connection	
	position does not follow the user manual	
	requirement of water-proof treatment.	

LEADING OUT OF PROFESSIONALISM

